



Email: info@paulcomp.com

Phone: 530-345-4371

11204 Midway

Chico, California 95928



1" & 1 1/8" Installation

Loosen the M5 x 10 clamp screw on the Funky Monkey. Install Funky Monkey onto the steerer tube (between the stem and headset) as you would a headset spacer. If there is any interference adjust as needed.

Install stem cap (and spacers above stem if needed). Adjust the headset bearing pre-load according to the manufacturer's specifications.

Align stem and funky monkey to be centered over front wheel.

Tighten stem clamp screws to manufacturers specifications.

Tighten Funky Monkey to 5Nm.

7/8" Installation

Loosen the M5 x 10 clamp screw on the Funky Monkey. Install Funky Monkey onto shaft of quill stem.

Install quill stem into headset to appropriate height. Center stem over front wheel and tighten stem in place.

Lower Funky Monkey toward locknut of headset but leave a small gap.

Center Funky Monkey and tighten to 5Nm.