



Email: info@paulcomp.com

Phone: 530-345-4371

11204 Midway

Chico, California 95928



The Funky Monkey Rear gives your bike the ability to work with cantilever or center pull brakes that have a straddle cable and require a cable stop above the rear brake.

Remove seatpost from seat tube.

Install Funky Monkey Rear onto seat post.

Insert seatpost into seat tube, adjust to proper height, and tighten seat clamp.

Adjust height of Funky Monkey Rear as needed then center over rear brake.

Tighten Funky Monkey M5 x 16 to 5Nm.

