



Email: info@paulcomp.com

Phone: 530-345-4371

11204 Midway

Chico, California 95928



**Stem
Cap
Light
Mount**



Remove existing stem cap from bike.

Install Stem Cap Light Mount with the mount towards the front of the bike using the provided M6 x 40mm screw.

Check headset as per manufacturer's guidelines.