



Email: info@paulcomp.com


Phone: 530-345-4371

11204 Midway


Chico, California 95928



**DROPPER
TRIGGER**



The PAUL Dropper Trigger can be used with most cable operated dropper seat posts. There are provisions for the cable head and a cable clamp if the head is used on the seat post.



Read and familiarize yourself with the instructions for your dropper seat post. Clamp the Dropper Trigger to the handle bar with a torque recommended by your handle bar manufacturer.

When it is required that the head of the cable be housed in the dropper trigger, you will need to loosen the cable clamp screw and washer and slide the cable underneath. Snug the bolt to the cable so it does not vibrate out on the trail.

When the head of the cable resides in the seat post, make sure the cable is threaded in the slot in the lever and between the lever and washer. **DO NOT** clamp the cable between the washer and screw head.

Use the provided barrel adjuster to remove any slack from the cable. Test the dropper post several times to make sure it is releasing/re-clamping