





Email: info@paulcomp.com
Phone: 530-345-4371
11204 Midway
Chico, California 95928



KLAMPER PISTON REPLACEMENT KIT





ITEM NO.	PART NO.	QTY
1	THRUST WASHER	1
2	THRUST BEARING	1
3	ACTUATOR ARM PISTON	1
4	7/32 BALL BEARING	3
5	PAD PISTON	1
6	KLAMPER SPRING	1

FULL KLAMPER
REBUILD VIDEO



Before installing the Klamper Piston Replacement Kit you must remove the retention screw for the actuator arm pad adjuster (the screw holds a ball bearing and spring in the hole, don't lose them). **Failure to do so may damage the pad adjuster.**

All 6 parts must be removed from the Klamper body before installing the replacement kit.

Clean out the old grease in the Klamper body and put ample fresh grease inside the body.