



Welcome to the wonderful world of the PAUL Set N' Forget thru axle quick release skewer. These will require an initial setup for optimum performance. Please follow the instructions carefully.

#### INSTALLATION:

1. Screw the Set N' Forget into the frame or fork as normal; screw the unit in with the lever in the open position until the head is about a dime's width from the dropout. Close the lever as with a normal quick release. You'll notice to get the proper tension the lever may end up in an unwanted position.
2. Decide where you want the lever to be. Visually calculate how much you need to rotate the head to get this position.
3. Release the lever and unscrew the QR a few turns. Open the lever then push **the ENTIRE head/lever portion** of the Set N' Forget and rotate to the desired position. The head can be rotation indexed into 12 different locations.
4. With the lever in the open position screw the unit back in until the head is about a nickel's width away from the frame/fork and close the lever.
5. A fine tuning may be needed but once you have the unit set, you can forget it. Just screw in the QR to your desired location and close the lever.